


Kwikset

Kwikset




**The User's Manual of PF
Euro Mortise Electronic Door Lock APP**

Registration and Login	2
Family Settings	4
APP Basic Settings	9
Door Lock Pairing	13
Door Lock Settings	16
Password Users	18
Remote Control	23
History	27

Follow the Setting Manual to download and install the APP, open the APP to log in or register for an account.


Register an Account

1. Click to "Account Registration"
2. Select to register with cell phone number or email address
3. Select country calling code
4. Enter cell phone number or email address
5. Click Next



After receiving the verification code on your mobile device


1. Enter the verification code
2. Enter your login password



Registration and Login

Account Log in

1. Enter cell phone number or email address
2. Enter password
3. Click Login
4. Enter the Home Page



Family Settings

Before pairing with the door lock, please be sure to create a new family before proceeding with the pairing.


Family Creation

Enter the menu at the upper left corner on the home page

1. Select My families
2. +Add new family
3. Enter family name

Note:


The first account that created the family would be the primary administrator.



Family Settings


Add member to the family

1. Select a family to add a new member
2. +Add member to the family
3. Select the member's type of account (Email or cell phone number)
4. Enter cell phone number or email address
5. Enter member alias
6. Select member Role
7. Add



Primary Administrator (Owner)

1. Has the highest authority in the family, being able to add/delete any administrator or general user from the family.
2. Has the authority on door lock pairing.
3. Has the right to the remote video, voice intercom (Applicable to some models), and remote unlocking.
4. Has the authority on sending a password remotely.
5. Has the right to rename the family.
6. Has the authority on modifying member Role.
7. Has the authority on moving the door lock device to another family.



Administrator (Manager)

1. Has the second highest authority in a family, being able to add/delete any general user from the family.
2. Has the authority on door lock pairing.
3. Has the authority on the remote video, voice intercom (Applicable to some models), and remote unlocking.
4. Has the authority on sending a password remotely.
5. Has the authority on renaming the family.
6. Has the authority on moving the door lock device to another family.

User

Has the lowest authority in a family, can only access the remote video, voice intercom, (Applicable to some models), and remote unlocking.


Family Settings

Family Renaming

1. Select Family Name
2. Press confirm after entering the new Family name



Note:

Only primary administrators and administrators have the authority on renaming.



Transfer of Authority of the Primary Administrator

1. Click on Transfer family
2. Scroll up and down to select the destination of the transfer (Administrators or General Users)
3. OK
4. Transfer





APP Basic Settings

Setting or changing of the secure password

Enter the menu at the upper left corner on the home page



1. Click on My Settings
2. Set security password
3. Enter the updated (new) secure password
4. Enter the original secure password or log in password for verification



Change login password

Enter the menu at the upper left corner on the home page

1. Click on My Settings
2. Modify login password
3. Press confirm after entering the updated (new) login password
4. Enter the original password, press confirm or verify the secure password








APP Basic Settings

Door Lock Notifications (On/Off)

Enter the menu at the upper left corner on the home page

1. Click on My Settings
2. Door lock notification
Turn on notifications (turned on by default)
3. Click Turn Off Notifications to turn off notifications. If notifications are turned off, any notifications from the door lock will not be sent to the APP.
4. If the toggle switch button below is turned on, the door lock will only send alarms, warnings, and remote unlocking notifications to the APP.


Note:
With the notifications turned on by default, any door lock alarms, warnings, unlocking notifications, and remote unlocking notifications can be sent to the APP.





APP System Settings

1. Click on APP System Settings
2. Connect to the mobile APP information and select Notifications
3. Turn on show notifications/allow notifications



Note:
Please make sure that APP notifications is turned-on on your mobile device. If not, you will not receive any door lock notification. It is recommended that both the door lock notifications and the APP system settings (cell phone notification) be turned on.



Android systems



IOS systems





Door Lock Pairing

The door lock pairing methods can be divided into two modes: Wifi Connection and QR code scanning (Applicable to some models).

Wifi Connection

1. Click on the Add button at the upper right corner (+Add Lock) or the +Add Lock button in the middle.
2. Select Wifi Connection
3. Please refer the Setting Manual, and turn on the Wifi connection.
4. Navigate from the APP interface to the home screen of your mobile device, select the phone Settings, and go to the Wifi network search page.
5. Select the name with CloudHome connect to it until the “connected without Internet” notification pops up. Then, proceed to the next step.
6. Navigate back to the APP interface, wait for the blue lights (2) and (3) to light up, and then proceed to the next step.
7. The APP will automatically search for Wifi networks nearby. Please select the Wifi network you want to connect the door lock to, or click on the Enter Manually button at the upper right corner.
8. Enter the name and password of the Wifi network manually, click next to connect.
9. Wait for the door lock to be connected to the Wifi network When a “Finish” message is displayed on the screen, the pairing is successful.
10. After click “finish” please enter door name.

Note: Wifi can include wireless sharing devices or mobile hotspots. The Wifi chosen must have a bandwidth of 2.4GHz.



Door Lock Pairing

QR Code Scanning (Applicable to some models)

1. Select QR Code Scanning.
2. Please refer to the instructions for the External Screen Function Settings in the Setting Manual, and turn on the Wifi connection.

(System Settings→Networking
→Wifi Connect).

After the Wifi connection is turned on, Tick the Confirm check box and click on "Start Connect" in the APP interface.


3. Enter the name and password of the Wifi network to be connected. Click on "next" to generate the QR code instantly.

4. Point the mobile device with the QR code display directly in front of the door viewer lens for scanning. The scanning distance is about 5-20cm.

If the scan is successful the door lock will beep, and the voice guide will indicate that the door lock is connecting to the network. until the "Finish" message is displayed, then the pairing is successful.

Note:

Wifi can include wireless sharing devices or mobile hotspots. The Wifi chosen must have a bandwidth of 2.4GHz.



Door Lock Settings


Renaming of the Door Lock

1. Door lock
2. Click on "More" at the upper right corner and select "settings"
3. Select the name of the door lock
4. Enter the new name for the door lock

Note:


The signal strength must be greater than 30%.

(The signal strength depends on the distance between the door lock and the wireless network sharing device.)




Moving the Door Lock Device to Another Family and Deleting a Door Lock Device

1. Click "more" to select Settings
2. Select Move to other Family (follow the guidance in step 3 and operate accordingly), If you choose to remove the door lock device from the family (follow the guidance in step 4 and operate accordingly)
3. Scroll up and down to select a family, and click on "OK"
4. Click Remove to complete the deletion



Note:


1. If the door lock has been restored to its factory defaults, please remove the door lock data on the APP accordingly.
2. If the door lock device in this family is to be moved to another family, the account must have more than 2 families. It must also be the primary administrator or administrator in these families.



The password users send passwords remotely. Once the passwords are generated in the mobile APP, they can be shared with friends or visitors through communication APPs. They can be categorized into one-time, periodic or permanent passwords. The use of the passwords can also be restricted to a specific period of time.

Set up Password Users

1. Select Password Users
2. Enter secure password for the security verification (or click "Click to Switch" to enter your login password)
3. Click + to set up password users





Password Users

One-Time Password Settings

1. Enter user name and click on once
2. Show Advanced Settings
3. Set password validity period (Unlimited or Custom)
4. Click on Next
5. Passwords can be randomly generated or entered manually.
6. Press and hold the blue image to share the password with friends or visitors.
The image will also be automatically saved to your mobile device.
7. Click on Close to complete

Note:

1. One-time password can be used once for an unlimited period of time to unlock the door lock, or once in a limited period of time to unlock the door lock.
2. After the password is generated, it is normal that the display shows that it is not synchronized. The password will be synchronized as soon as you activate the touch button.





Periodic Password Settings

1. Click on Permanent
2. Show Advanced Settings
3. Click on Custom
(Set password validity period according to personal needs)
4. Click on Next
5. Passwords can be randomly generated or entered manually.
6. Press and hold the blue image to share the password with friends or visitors.
The image will also be automatically saved to your mobile device.
7. Click on "Close" to complete

Note:

Periodic password allows unlimited access to unlock the door lock within the validity period.





Password Users

Permanent Password Settings

1. Click on Permanent
2. Show Advanced Settings
3. Select Unlimited
(Set password validity period according to personal needs)
4. Click on Next
5. Passwords can be randomly generated or entered manually.
6. Press and hold the blue image to share the password with friends or visitors.
The image will also be automatically saved to your mobile device.
7. Click on "Close" to complete

Note:

The permanent password has no expiration date and can be used to unlock the door lock an unlimited number of times.





Change Password

1. Select user name
2. Click on the edit icon at the upper right corner
3. Click on Update Password
4. Enter the password you want to change (passwords can be randomly generated or entered manually).
5. Press and hold the blue image to share the password with friends or visitors. The image will also be automatically saved to your mobile device
6. Click on "Close"

Delete User

1. Select user name
7. Click on Remove User





Remote Control

When the active viewing function is disabled (default), family members can watch the real-time screen outside the door, perform remote intercom and unlock the door only after the visitor presses the doorbell. If the active viewing function is turned on, you can watch the real-time screen outside the door at any time, and perform remote intercom and unlock.

APP Active view function (Applicable to some models)



1. Click "more" to select Video settings.
2. Open Active View.
3. Wake up the button screen until the APP displays "configuration has taken effect".
4. Go back to the history page, click the circular icon above, you can directly watch the real-time screen outside the door, and perform remote intercom and unlock.)



When a visitor presses the doorbell, you will immediately receive a call on your mobile device with a remote unlocking request notification. The APP will start automatically when the call is answered. At the same time, you can watch the live display outside the door and conduct remote intercom. You can also remote unlock the door lock directly.

Remote Video and Voice Intercom (Applicable to some models)

1. When a call is received on your mobile device, click on "Pick up".
2. You will enter the remote unlocking request page in the APP, click ▶ to enable the remote video and voice intercom.
3. After enabling the remote video and voice intercom, you can not only observe the visitors outside the door, but also hear their voice outside the door on your mobile device. If the cell phone user wishes to speak to the visitors outside the door, just press and hold the "Hold to Speak" button at the bottom to talk. Release the button immediately after you finish speaking.



Note 1: If the screen shows "connected by other family member", the remote video and voice intercom is currently being viewed by another member. Only one member can view the intercom at a time.

Note 2: Starting from the incoming of the call, the remote video and voice intercom must be turned on within 60 seconds, if fail to do so within the time limit, the video and voice intercom will not be available.




Note 3: When you press and hold the "Hold to Speak" button at the bottom, you won't be able to hear the voice outside the door, unless you release the button.

Remote Control

Remote Unlocking (Applicable to some models)

1. Click on Unlock after the video and voice intercom is enabled.
2. Enter secure or login password





Note:
Clicking on the "Ignore" button will interrupt the remote video and voice intercom and return to the History page.



Remote Unlocking (Applicable to some models)

When the user touch door bell sign the lock. The APP will be receiving the unlock message.

1. Click on door bell, the APP will be received message and then click the message.
2. Enter the APP, then click "unlock"
3. Enter password will unlock the lock.



History

Records the users' various unlocking information and various alarms and warnings.

Change User Name

1. Click on "More" to select from the user list.
2. Click on the user name to be changed.
3. Enter the new name.
After clicking on Confirm, the new user name will replace the original default unnamed name.

Note:

Only records in the last 30 days are displayed in the History.
There is no limit to the number of records per day.

